
Adjust the length of the tripod legs by pressing on the red button and fold the black plastic part.



Place the tripod in a suitable position and height and use the libel to make sure the tripod is leveled. Detach the spreaders if needed.




Place the plate underneath the terminal, according to the pictures below., with front side first. Attach the hooks to the holes.





Press both hooks at the same time and make sure the plate gets into position.



Double check that the plate is in position by pressing both sides



Lift up and turn the Terminal and place the round part of the plate onto the center of the tripod.





With the terminal resting on the tripod, Hold the side that is furthest away from the center with one hand, and use the other hand to screw the handle placed underneath the tripod.



Screw it all the way in, and then make sure the terminal is in position.

Open the terminal, start it up and connect to a satellite. Adjust azimuth by rotating the base plate of the terminal. When in position, screw in the screw placed underneath, all the way to lock the terminal in place.





Demount

Start by folding the antenna of the terminal, and place one hand on the edge of the terminal. Use the other hand to unlock the handle underneath. Then lift the terminal with both hands on the terminal.