


Peplink MAX User Manual

MAX BR1 Mini 5G



LED Indicators

The statuses indicated by the front panel LEDs are as follows:

Status Indicators



Status	OFF	System initializing
	Red	Booting up or busy
	Blinking red	Boot up error
	Green	Ready

Cellular Indicators

Cellular	OFF	Disabled or no SIM card inserted
	Blinking slowly	Connecting to network(s)
	Green	Connected to network(s)

© 2022 Peplink | Pepwave. All Rights Reserved.

