


# Peplink MAX User Manual

## MAX BR1 Mini M2M



### LED Indicators

The statuses indicated by the front panel LEDs are as follows:

### Status Indicators

---

<b>Status</b>	OFF	System initializing
	Red	Booting up or busy
	Blinking red	Boot up error
	Green	Ready

---

### Cellular Indicators

---

<b>Cellular</b>	OFF	Disabled or no SIM card inserted
	Blinking slowly	Connecting to network(s)
	Green	Connected to network(s)

---

### Wi-Fi Indicators

---

<b>Wi-Fi</b>	OFF	Wi-Fi AP is turn off
	ON	Wi-Fi AP is turn on

---