


Peplink MAX User Manual

MAX BR2

Panel Appearance





LED Indicators

The statuses indicated by the front panel LEDs are as follows:

Status Indicator

| Status | OFF | System initializing/power off |
|--------|---------------------|-------------------------------|
| | Red | Booting up or busy |
| | Blinking red | Boot up error |
| | Green | Ready |

Cellular Indicators

| | | |
|-------------------|-----------------|----------------------------------|
| Cellular 1 | OFF | Disabled or no SIM card inserted |
| | Blinking slowly | Connecting to network(s) |
| | Green | Connected to network(s) |



Cellular Indicators

| | | |
|-------------------|-----------------|----------------------------------|
| Cellular 2 | OFF | Disabled or no SIM card inserted |
| | Blinking slowly | Connecting to network(s) |
| | Green | Connected to network(s) |

© 2022 Peplink | Pepwave. All Rights Reserved.

