

Peplink MAX User Manual

BR2 Micro

Panel Appearance



LED Indicators

The statuses indicated by the front panel LEDs are as follows:

Status Indicator

Status	OFF	Power off
	Red	Booting up
	Green	Ready

Status Indicator

USB-C	OFF	System initializing/power off
	Blinking	Data is transferring
	Green	Port is connected without traffic

Status Indicator

WAN/LAN	OFF	System initializing/power off
	Blinking	Data is transferring
	Green	Port is connected without traffic